

## NanoContact Printing Using a Stamp Fabricated by UV Nanoimprint Lithography

Xiaoyin Xiao<sup>1</sup>, Jian Gu<sup>2</sup>, Peiming Zhang<sup>1</sup>, Bharath R. Takulapalli<sup>2</sup>, Michael Morrison<sup>1</sup>, Frederic Zenhausern<sup>2</sup>

<sup>1</sup>Center for Single Molecule Biophysics, <sup>2</sup>Center for Applied NanoBioscience, The Biodesign Institute at Arizona State University, Tempe, AZ 85287  
[Jian.Gu@asu.edu](mailto:Jian.Gu@asu.edu); [Peiming.Zhang@asu.edu](mailto:Peiming.Zhang@asu.edu)

Contact printing has many applications including flexible electronics, biosensors, catalytic surfaces, and cell biology.<sup>1</sup> Stamp is a critical component in contact printing. Original contact printing used a soft-PDMS stamp, which is capable of printing microscale patterns ( $\mu$ CP), but not nanoscale patterns (nCP) due to mechanical strength induced defects of the soft-PDMS. Since then, different stamp materials and structures have been proposed towards nanoscale printing for different applications, such as hard-PDMS, HSQ, flexible or rigid back supports etc. In this work, we use a stamp fabricated by UV nanoimprint lithography with a thin elastic layer *and* a thin rigid back support. The thin elastic layer is expected to reduce stamp distortion during printing; the rigid back support offers mechanical strength of the stamp for less in-plane distortion; and the thin thickness of rigid support allows low pressure printing, which is important in decreasing stamp/substrate deformation for reduced distortion and stamp protection.

The detailed fabrication process is as follows: a Si master with pillar arrays of 160-nm-depth and feature/pitch as small as 50/150 nm is fabricated by EBL, Cr evaporation, liftoff and dry etching; nCP stamp with the same features as on the master is fabricated by double UV nanoimprint using Nanonex 2010 UV resist (180-nm-thick) with an underlayer (200-nm-thick) on a thin cover glass (150- $\mu$ m-thick) (Fig. 1a); then nCP is carried out on a SiO<sub>2</sub>/Si wafer in a gas-pressed UV-imprint chamber with a pressure of 40-80 psi and time of 1-30 min. Different chemistries have been demonstrated by nCP and nanoarrays are characterized by fluorescence microscopy and atomic force microscopy (AFM).

Fig. 1b shows a SEM picture of 50/150 nm array after Cr liftoff on Si master. Fig. 1c shows an AFM image of 50/250 nm array on nCP stamp. Fig. 2a shows confocal fluorescence image of FITC arrays with different feature/pitch sizes printed on aminosilane treated substrate; fig. 2b-c show AFM images of 50 nm and 200 nm feature streptavidin protein arrays with a uniform thickness of 3 nm fabricated by printing NHS-biotin on the aminosilane treated substrate followed by biotin-streptavidin interaction. Stamp feature aspect ratio, durability, printing pressure, potential for multilayer printing and surface chemistry will be discussed.

The authors thank Prof. Stuart Lindsay for his support of the project and the use of AFM.

<sup>1</sup>A. P. Quist, E. Pavlovic, S. Oscarsson, *Anal. Bioanal. Chem.* **381**, 591 (2005)




Figure 1 a) Schematics of nCP stamp fabrication by double UV nanoimprint; b) SEM image of 50/150 nm array after Cr liftoff on Si mater; AFM image of 50/250 nm array on nCP stamp.




Figure 2 a) Confocal fluorescence image of FITC arrays of different feature/pitch sizes; b-c) AFM images of 50/250 nm and 200/500 nm streptavidin protein arrays by nCP.